



AirDeck®

AirDeck

A FALL ARREST SYSTEM
FOR SAFETY AND EASE OF USE



METHOD STATEMENT



SAYFA
SYSTEMS UK

AIRDECK INSTRUCTIONS AND INSTALLATION GUIDE

Installers should adhere to all current Health and Safety Rules, such as the wearing of protective clothing, i.e hard hat, high visibility Vest/Jacket, metal toe capped boots and hand protective gloves. AirDeck products comply to the PAS59:2014 safety standard.



1. Ensure the area is free from debris. Lay out the AirDeck bags to allow for complete floor coverage.



3. Open the access flap and expose the valve. Remove the screw cap.



2. Make sure that the inflator, 110v, 220v or 4 stroke, is ready for use.



4. Insert the Inflator through the valve and inflate with the Inflator at maximum





5. Fully inflate the liner until it completely fills the outer.



7. On full inflation of the AirDeck, make sure that the liner does not protrude and that the flap will close fully to protect the liner.



6. Once the liner is full of air screw the cap on tightly.



8. Should this not be the case deflate the liner slightly and adjust by pulling the liner through the access overlap flap at the far end of the liner.





9. Add more bags by following Steps 1-7 and clip them together



11. To deflate the bags remove the valve screw cap. Push back the flap using the red tab until it locks in position. Using the extract facility on the pump if it has one draw out all the air. Alternatively the bags will deflate fairly rapidly if the valve is just left open.



10. Cover the whole floor area. Clip the last bag in the row to its neighbour before inflating further bags. If necessary, partly inflated bags can be squeezed in to small or awkward gaps.



12. Make sure the bags are fully delated and then fold for on-site storage. Take care to store the bags and liners in a protected environment.

Care and Maintenance

With care, regular inspections and under normal conditions of use and storage you might expect a full working life of up to 3 years.

- Please make sure you follow all recommendations for use as indicated on the liner taking particular care not to walk on the liners when setting out for deployment and that no sharp objects are within the folds when folding for storage
- Wherever possible store in a cool dark place and avoid both extremes of temperature and wide and rapid fluctuations of temperature
- Increased and rough handling may cause fabric failure and will result in a reduction of operating life. The year and month of manufacture is marked on each liner as a guide to the operating life you might expect.
- Check that the liner stays inflated at each deployment and replace if necessary.
- Keep a record of checks, use and frequency of deployment.

Sayfa Systems UK Ltd
 Jubilee House
 No. 3 Gelders Hall Road
 Shepshed
 Loughborough
 Leicestershire
 LE12 9NH

T: 0845 241 9102
 F: 0845 130 4520
 email: info@sayfasystems.com
www.sayfasystems.co.uk